



RIPPLE METER

MODEL: THIS MANUAL APPLIES TO ALL MODELS:

290-RPL-BATT 290-RPL1 290-RPL2 290-RPL2-N 290-RPL3

CONTENTS:

- I. OVERVIEW OF THE RIPPLE METER
- II. RIPPLE METER OPERATION
 - A. MAIN DISPLAY SCREEN (ALL MODELS)
 - B. SETUP SCREEN

Section	Screen	290-RPL1 290RPL-BATT	290-RPL2	290-RPL2-N	290-RPL3
1.	RELAY ENABLE		▪	▪	▪
2.	LOW RIPPLE		▪	▪	▪
3.	HIGH RIPPLE		▪	▪	▪
4.	LOW DC VOLT		▪	▪	▪
5.	HIGH DC VOLT		▪	▪	▪
6.	MINIMUM DC VOLT		▪	▪	▪
7.	ALARM DELAY		▪	▪	▪
8.	AVERAGING FILTER	▪	▪	▪	▪
9.	NETWORK			▪	
10.	BOX W /AUDIO & LIGHT ALARMS				▪

REV 08/16/12

CHECK FOR FREE MANUAL UPDATES AT www.jpotech.com

JP Tech, Inc. ▪ Box 863 ▪ 2286 Church Street, UNIT C ▪ East Troy ▪ WI ▪ 53120
Phone (262) 642-7671 ▪ Fax (262) 642-7681

I. OVERVIEW FOR THE RIPPLE METER

JP Tech's Ripple meters incorporate several setup screen options in the Menu designed for ease of operation, information gathering, and programming. All models incorporate a main display screen that shows DC voltage, AC voltage, percent of ripple, and alarm conditions.

All models use a two (2) button keypad to cycle through the Menu displays available and to set the parameters of the meter:

- ◆ The **SELECT** key, when pressed and released, cycles through the different screens available to the specific model. In all screens (except the Main display screen), holding the **SELECT** key for about 3 seconds will enable the flashing cursor; releasing and pressing again will position the cursor for a change to be made. Holding the **SELECT** key again for about 3 seconds will stop the flashing cursor. *The **SELECT** key will not change any existing information. It only provides a way to move through the menu or move the flashing cursor.*
- ◆ The **CHANGE** key is used to change a value or option related to the specific flashing display chosen with the **SELECT** key (for example to change the value of the **LOW RIPPLE %** or to **ENABLE** or **DISABLE** the **RELAY**). **NOTE: Pressing and releasing BOTH the **SELECT** and the **CHANGE** keys together once the flashing cursor stops, will take you back to the **MAIN DISPLAY** default screen.**

◆ **EXAMPLE FOR USING THE SELECT AND CHANGE KEYS:**

SETTING HIGH RIPPLE: From the **SETUP** screen, **PRESS/RELEASE** the **SELECT** key three (3) times. This will bring you to the **HIGH RIPPLE** screen. To enter any value or reset existing values, **PRESS/HOLD** the **SELECT** key for about 3 seconds until the **LEFT MOST DIGIT** begins to flash. When it flashes, release the **SELECT** key. If you want the digit that is flashing to stay the same, **PRESS/RELEASE** the **SELECT** key **ONCE**. This will move the flashing cursor over to the right one digit. **[This is the method used to move the flashing cursor over for all screens.]**

If you want to change the value of the flashing digit, **PRESS/RELEASE** the **CHANGE** key **ONCE**. Each time the **CHANGE** key is pressed and released, the value of the digit increases by one (1) and cycles from 0 through 9. **[This is the method used to change the value of the flashing cursor for all screen.]**

Once you have set the values you want, **PRESS/HOLD** the **SELECT** key until the flashing cursor disappears (about 3 seconds).

II. RIPPLE METER OPERATION


A. MAIN DISPLAY SCREEN

DC: 0.00	AC: 0.00
RPL: 0.00%	AHU

To the right is the **Main Display** Screen. This screen shows DC voltages, AC voltages, and the amount of ripple currently present. This screen auto-ranges from 0-600V with the DC and AC readouts auto-ranging separately. Percent ripple maximum is 999.99%. The lower right corner indicates the alarm status. Below is a list of the status symbols and their meaning.

ALARM STATUS SYMBOLS: (Some Symbols not on every model)

ALARM SYMBOLS:



The enabled ALARM engages when one or more of the set points are out of range. The ALARM disengages when all set points are within their ranges.

II. RIPPLE METER OPERATION (Cont.)

B. SETUP

A screenshot of the SETUP screen, showing the word "SETUP" in black text on a light green background, enclosed in a red rectangular border.

To the right is the **SETUP** screen. Behind this screen are the screens that enable/disable the alarm relay, program the set points for activating the alarm, sets the amount of delay before the Alarm condition is acknowledged, and enables/disables the averaging filters. To acquire these screens, PRESS/HOLD the **Select** key for about 3 seconds. Toggle to each subsequent screen with the **Select** key as well. **NOTE: To get back to the main screen any time while in SETUP, press/release BOTH keys at once.**

Programming: SEE "OVERVIEW"

1. RELAY ENABLE

A screenshot of the RELAY ENABLE screen, showing the words "RELAY ENABLE" in black text on a light green background, enclosed in a red rectangular border.

To the right is the **RELAY ENABLE** screen. This screen ENABLES or DISABLES the Alarm relay. This must be set to ENABLE for the relay to function. *The Alarm conditions (H,L,O,U, and V) seen on the MAIN DISPLAY screen will appear whether the relay is enabled or disabled but instead of an "A" indicating that the Alarm relay is enabled, there will be an "X" indicating that the relay is disabled.*

Programming: See "OVERVIEW"

2. LOW RIPPLE

A screenshot of the LOW RIPPLE screen, showing the words "LOW RIPPLE" and "000.00%" in black text on a light green background, enclosed in a red rectangular border.

To the right is the **LOW RIPPLE** screen. This screen sets the lower limit of ripple before the Alarm condition is engaged. Normally this is set to 0% ripple which disables this alarm condition (as the screen above is set = default setting). In some cases, however, when the ripple parameters are known, setting this screen to a value may be helpful to alert you to a potential problem with your rectifier. If the amount of ripple goes below this set point, an "L" will appear in the lower right hand corner of the MAIN DISPLAY screen.

Programming: See "OVERVIEW"

II RIPPLE METER OPERATION (Cont.)

3. HIGH RIPPLE

HIGH RIPPLE
000.00%

To the right is the **HIGH RIPPLE** screen. This screen sets the upper limit of ripple before the Alarm condition is engaged. This setting should be set high enough so that slight fluctuations due to AC power variations, barrel movement, etc. can take place without setting off the alarm. If the amount of ripple goes above this set point, a “H” will appear in the lower right hand corner of the MAIN DISPLAY screen. Setting this screen to 999.99v disables this alarm condition.

Programming: See “OVERVIEW”

4. LOW DC VOLTS

LOW DC VOLTS
000.00V

To the right is the **LOW DC VOLTS** screen. The alarm condition will be enabled when a voltage is encountered that is lower than what is set in this screen. For example, if this screen is set for 6 volts, any voltage below this value will engage the alarm condition. When this happens, a “U” would appear in the lower right hand corner of the MAIN DISPLAY screen. Setting this screen to 000.00V disables this alarm.

Programming: SEE “OVERVIEW”

5. HIGH DC VOLTS

HIGH DC VOLTS
000.00V

To the right is the **HIGH DC VOLTS** screen. The alarm condition will be enabled when a voltage is encountered that is above what is set in this screen. For example, if this screen is set for 6 volts, any voltage above this value will engage the alarm condition. When this happens, an “O” will appear in the lower right hand corner on the MAIN DISPLAY screen. Setting this screen to 999.00v disables this alarm.

Programming: SEE “OVERVIEW”

6. ALARM MIN DCV

ALARM MIN DCV
000.10V

To the right is the **ALARM MIN DCV** screen. The alarm will be disabled when the meter’s voltage is below the set point entered into this screen. For example, if this screen is set for 1 volt, any voltage below this amount will inhibit the alarm condition. When this happens, a “V” will appear in the lower right hand corner on the MAIN DISPLAY screen. To disable all the Alarm conditions, set this screen to 999.00v. **Keep this value to a least 0.10 DCV.**

Programming: SEE “OVERVIEW”

II RIPPLE METER OPERATION (Cont.)

7. ALARM DELAY

ALARM DELAY
01 SECONDS

To the right is the **ALARM DELAY** screen. This screen sets the amount of time, in seconds, before an alarm condition is reported to the MAIN DISPLAY screen. This function is used to prevent slight variations in ripple that happen over a short period of time from engaging the Alarm condition. A typical setting would be 4 to 6 seconds but may need to be longer depending on your rectifier's performance. **Need to set the Alarm Delay for a Min of 1 seconds.**

Programming: SEE "OVERVIEW"

8. AVERAGING FILTER

AVERAGING FILTERS
ENABLED

To the right is the **AVERAGING FILTER** screen. When enabled, this screen allows the ripple to be averaged over a period of time in order to smooth out peaks and valleys that may occur due to voltage fluctuations, barrels rolling, etc. The ripple percent will become more stable on the MAIN DISPLAY screen when this function is enabled.

Programming: SEE "OVERVIEW"

J P TECH: RIPPLE METER

SPECIFICATIONS

FUNCTION	RANGE	RESOLUTION	ACCURACY
DC VOLTAGES	6.00 V	0.01V	+/- (1.0% + 2dgt)
	60.0V	0.1V	+/- (1/0% + 2dgt)
	600V	1V	+/- (1.0% + 2dgt)

AC VOLTAGES	6.00V	0.01V	+/- (1.0% + 2dgt)
	60.0V	0.1V	+/- (1/0% + 2dgt)
	600V	1V	+/- (1.0% + 2dgt)

Accuracy is given as +/- (% of reading + number of least significant digits)
At 20 degrees C to 24 degrees C for a period of six months after calibration.

OPERATION AND BATTERY INSTULLATION

OPERATION:

NOTE: COULD BE EXPOSED TO HIGH VOLTAGES AND AMPERAGES. USE EXTREME CAUTION WHEN USING THIS INSTRUMENT.

1. Place the RED booted clamp on the POSITIVE output bus and the BLACK booted clamp on the NEGATIVE output bus.
2. Turn on the meter. ["0" = OFF and "1" = ON]
3. Read the DC and AC voltages and the Ripple on the LCD screen.

BATTERY REPLACEMENT:

1. Unscrew the four (4) screws holding the faceplate in place.
2. From the bottom of the faceplate, pry up and rotate forward.
3. Remove battery from holder and replace with the new one.
4. Replace lid back onto the enclosure and secure with the four screws.

TYPICAL INSTULLATION (NOT BATTERY POWERED)

1. Connect the RED lead to the Positive Bus bar on the Rectifier or at the Positive Bus bar at the tank.
- 2.. Connect the BLACK lead to the Negative Bus bar on the rectifier or at the Negative bus at the tank.
3. Power the Ripple meter from a 110VAC source. Please Note: No off/on switch; disable by un-plugging the unit.

NOTE: MAY NEED ADDITIONAL WIRE AND TERMINAL STRIP TO MAKE THE CONNECTIONS TO THE BUS BAR OR TANK. IF SO, MAKE SURE WIRE IS HEAVY ENOUGH FOR TOTAL VOLTAGE POSSIBLE.

JP TECH, INC.

LIMITED PRODUCT WARRANTY

JP Tech warrants to first user of each new JP Tech product or component that it is free from defect in material and workmanship. The obligations of JP Tech under this warranty are expressly limited to the following:

- JP Tech will repair or replace, at its option, any defective components for a period of twelve (12) months from date of shipment. No charges are covered for the removal or replacement of defective components.
- This warranty applies only if the product is defective under normal use. It does not apply to breakage or defect from accident, alteration, misuse, or abuse of the product or component. In addition, this warranty is effective only if the product or component is installed in a location and manner prescribed by JP Tech's instructions and only if it is so maintained. This warranty becomes null and void if the product or component is altered by anyone other than JP Tech, its authorized representatives, or by expressed written authorization for a specific situation.
- If JP Tech elects to send a service technician to a customer site to repair a defect, the cost of transportation and/or living expenses will be paid for by the customer. Should the defect turn out to be the result of the customer's misuse, improper installation, or maintenance of the product or component, the customer will be responsible for the full cost of the service call including labor charges plus the aforementioned travel and living expenses.
- JP Tech will repair or replace any defective part within a product at the sole discretion of JP Tech. If JP Tech should choose to supply a part to the customer as a no-charge warranty replacement, the customer assumes all cost of installation associated with the replacement part. If the product needs to be returned for warranty service, a Returned Material Authorization (RMA) must be issued by JP Tech prior to such return. All returned material must be sent freight prepaid or it will not be accepted by JP Tech irrespective of warranty issues.
- There are no implied warranties of merchantability or of fitness for a particular purpose. The above warranty is made in lieu of all other guarantees or warranties, express or implied. JP Tech distributors or OEMs who purchase JP Tech products for resale are not authorized to assume any other obligation or liability for JP Tech.
- JP Tech will in no case or under any circumstances be liable for special, incidental or consequential damages, loss of profit or commission for any loss caused by any delay in production or shipment of product, or defect of any kind in any product or component covered by the sale. Without limitation, JP Tech will not be so liable with respect to furnishing of any product, or component, delay in such furnishing, use, resale, or other cause. JP Tech's liability arising out of the supply of any product or component, its use, resale or other disposition, or out of any guarantee or warranty, express or implied, or any other cause, shall in no way exceed the cost to JP Tech of the product or component which JP Tech agrees to repair or replace. JP Tech's liability for any product or component terminates upon expiration of the applicable repair or replacement period.

This implementation of this warranty may, under separate agreement, be subrogated to exclusive distributors or manufacturers who shall assume all or portions of the liability associated with warranty costs.

This warranty may be modified, wholly or in part, at any time by JP Tech without notice to past or future customers. The warranty revision in effect at the time of shipment shall prevail in any claims rendered.

Revised 10/3/01

JP TECH, INC.

TERMS AND CONDITIONS OF SALE

The purchase of any products or services supplied by JP Tech shall be governed by the terms of this agreement. Purchaser of these products and services acknowledges and agrees to these terms without modification by any competing document or any agreement not reduced to writing and authorized by an officer of JP Tech, Inc.

- Pricing is the effective price at the time of the order. If the shipment of product is postponed by buyer, the price may be changed to reflect any price changes enacted by JP Tech. Prices may be changed by JP Tech at any time for any reason without notice to purchaser except for accepted orders not affected by a purchaser initiated delay. Prices, unless otherwise stipulated, do not include shipping and handling charges.
- Certain products may require initial and progress payments before the commencement and continuation of design, engineering, component procurement, and manufacture. These products will not be shipped until all progress payments have been made. Cancellation of any orders in progress will necessitate the forfeitures of any payments received to date as well as payment of any costs accrued in excess of paid amounts.
- Orders must be accepted by JP Tech at their home office. Acceptance of any purchase order, regardless of the method, is conditioned on assent of buyer to the terms and conditions contained herein.
- Sales are FOB point of shipment. Sales terms are net 30 days from date of shipment. Present or future sales, use, or other taxes on sales, installation or use shall be paid by purchaser. Purchaser shall pay 1% interest per month on all outstanding amounts due to JP Tech. Interest accrual shall begin on the 31st day after shipment for all outstanding amounts.
- All sales are final. Any decisions to accept return of product after shipment and receipt by purchaser shall be at the sole discretion of JP Tech and not until payment has been made and agreement by purchaser to pay all shipping, cancellation, and restocking charges that may accrue.
- Shipping dates given prior to shipment are estimated, actual delivery will be based on factory and engineering loading at the time of manufacture as well as the availability of parts required for manufacture. JP Tech shall not be liable for any costs or damages arising out of or related to any delays in shipment or delivery, including but not limited to liquidated damages, unless otherwise agreed in writing.
- JP Tech may change design or construction of any product or component in any way they see fit. Upgrades for previously purchased products may be available for certain products for a price that will be determined when appropriate.
- Except as provided herein, any controversy, claim or dispute arising out of or related to any order or sale or breach thereof, including but not limited to any breach of warranty claims, shall be litigated in state court, Walworth or Waukesha Counties, Wisconsin, and shall be governed by the laws of Wisconsin. If JP Tech is the prevailing party, JP Tech shall be entitled to collect all reasonable fees and costs, including court costs and attorney fees.